
Vortex flow meter

Installation manual

Table of contents

Directory.....	1
Foreword.....	2
1. Overview	3
2. Technical parameters.....	4
3. Structural appearance	6
4. Instrument installation	7
5. Cable connection method	9
6. Commissioning and operation	12

Foreword

Thank you for purchasing the vortex flow meter developed and produced by our company.

This manual documents how to use this product correctly and safely, reducing the loss of accuracy or damage to the instrument due to the installation or use environment.

The flow meter can be measured using gas, steam and liquid, but due to different ordering specifications and models, different media may damage the instrument.

- After reading this manual, please flow with the instrument and keep this manual in a safe place.
- Please submit this manual to the end user technical department for later use.
- Please carefully review this manual before installation, and follow the contents of this manual during installation to avoid affecting accuracy or damage to the instrument.

Note:

- a. **Power supply mode:** The vortex flow meter produced by our company, except for the integrated calculator or power supply, if DC power supply is required, the power supply is DC24V DC power supply, the battery power supply is DC3.6V, any does not meet the power supply conditions and is caused by power supply. The damage is not covered by the warranty. It is recommended to use brand power or system power supply. Vortex is a low-power meter, and the maximum power consumption current will not exceed 30mA.
 - b. **Explosion-proof statement:** The company's instrumentation line uses intrinsically safe circuits, but customers must also declare in advance when using in explosive gas environment. Explosion-proof type meters and conventional meters have certain differences, so the production process is slightly different. In addition, In an explosive atmosphere, it should also be carefully installed and used in accordance with explosion-proof requirements.
 - c. **Degree of protection:** The company's conventional product protection grade is IP65, which means that it does not affect the dust entry and the low pressure injection liquid at any angle. However, if the internal circuit is exposed to humid air, it will affect the meter. Therefore, in a humid environment, seal the case, wiring, etc. If there is water inside the case, immediately turn off the power and blow in a dry environment. Dry seal. In the environment where it is often raining, it must be properly protected.
 - d. **Use environment:** Since the vortex flow meter is very sensitive to vibration, the pipeline should be smooth and vibration-free, and there is no large-scale substation equipment around to generate high-frequency electromagnetic interference waves.
-

The ambient temperature should be in the range of $(-25^{\circ}\text{C} \sim 55^{\circ}\text{C})$.

The ambient humidity should be in the range of (5% to 90%).

- e. **Medium condition:** The meter should meet the full tube of the medium and meet the corresponding temperature and pressure requirements. The temperature and pressure should not exceed the specified range to avoid damage to the meter. For negative pressure media, the measurement should be stated in advance. If pressure compensation is used, a negative pressure sensor should be used.

This manual is based on:

《JBT 9249-2015 Vortex flow meter》


《JJG1029-2007 Vortex flow meter verification procedure》

write。

1.Overview

The vortex flow meter produces a velocity flow meter based on the Karman vortex principle for measurement and metering of conventional gases, vapors and liquids. The vortex flow sensor has high precision and a wide range ratio. It has no moving parts in use, which can improve mechanical stability and reduce maintenance. Vortex is almost unaffected by the temperature, pressure and composition of the medium when measuring the working volume, so it is convenient for the calibration production of the instrument. Therefore, the vortex flow sensor is widely used in production and life.

When a triangular column type vortex generator is provided in the fluid, regular vortices are alternately generated from both sides of the vortex generator. These vortices are called Karman vortices, and the vortex rows are arranged asymmetrically downstream of the vortex generator. Vortex is produced according to this principle. The vortex is generated by the generating body, and the high-sensitivity sensor detects the number of vortices. The number of vortices generated in a certain range is proportional to the flow rate, so the flow rate can be calculated by a precision processor.



In a vortex flowmeter, the relationship between the flow rate and the number of vortices generated can be the following formula:

$$Q = \frac{3600F}{K}$$

Q : The working volume flow rate of the measured medium is measured by the company in m³/h.

F : The frequency of the number of vortices generated by the body, the company in Hz.

K : Refers to the calculated or calibrated flow coefficient, which represents how many frequency signals are in each cube, which is generally derived from calibration.

Standard table method calibration coefficient K formula:

$$K = \frac{\text{Checked table traffic } Q_{Be}}{\text{Standard table flow } Q_s} \times K_{\text{coefficient}}$$

(This formula can also be used for flow correction)

2. Technical Parameters

Main technical parameter list

Nominal diameter(mm)	15、20、25、40、50、65、80、100、125、150、200、250、300、 (300~1000 Plug-in)
Nominal pressure(MPa)	DN15-DN200 4.0(>4.0 Agreement supply), DN250-DN300 1.6(>1.6 Agreement supply)
Medium temperature(°C)	Piezoelectric: -40~100, -40~250, -40~330; Capacitive: -40~400, -40~500 (Agreement supply)
Body material	1Cr18Ni9Ti, (available under other materials agreement)
Allowable vibration acceleration	Piezoelectric:0.2g Capacitive:1.0~2.0g
Accuracy	$\pm 1\%R$, $\pm 1.5\%R$; Plug-in: $\pm 2.5\%R$,
Range	1: 6~1: 25
Supply voltage	sensor: DC 24V (DC) ; Battery powered: 3.6V battery
output signal	Square wave pulse (excluding battery-powered type): high level $\geq$ supply voltage minus 1V, low level $\leq 1V$; current: 4 ~ 20mA
Pressure loss coefficient	Meet the JB/T9249 standard $C_d \leq 2.4$
Explosion-proof mark	EXiaIICT4 Ga
Intrinsic safety parameters	$U_i=28VDC$, $I_i=100mA$, $P_i=0.657W$, $C_i=0. \mu F$, $L_i=0mH$
Protection level	Ordinary IP65 diving type IP68
Environmental conditions	Temperature $-20^{\circ}C \sim 55^{\circ}C$, relative humidity 5% ~ 90%, atmospheric pressure 86 ~ 106kPa
Applicable medium	Gas, liquid, steam
Transmission distance	Three-wire pulse output type: $\leq 300m$, two-wire standard current output type (4~20mA) $\leq 1500m$; load resistance $\leq 500 \Omega$; RS485 $\leq 1200m$.

Vortex accuracy level series:

level of accuracy		1.0	1.5	2.0	2.5
Maximum influence error	$q_t \leq q < q_{\max}$	$\pm 1.0\%$	$\pm 1.5\%$	$\pm 2.0\%$	$\pm 2.5\%$
	$q_{\min} \leq q < q_t$	$\pm 2.0\%$	$\pm 3.0\%$	$\pm 4.0\%$	$\pm 5.0\%$
Note: Demarcation flow refers to $0.2 q_{\max}$					

Vortex flow range:

Different gauges measure the flow range. The meter selection process must be based on the flow range. The most taboo is to select the meter according to the thickness of the pipeline. The biggest drawback of selecting a meter based on a pipe is that it is easy to cause measurement errors due to insufficient flow.

The flow range determination of the vortex flowmeter is based on the working condition flow. Therefore, the meter selects the flow into the working condition flow and then compares the flow range table. As far as possible, the common flow is in the middle range of the meter measurement.

Instrument caliber (mm)	liquid		gas	
	Measuring range(m ³ /h)	Output frequency range(Hz)	Measuring range(m ³ /h)	Output frequency range(Hz)
15	0.8~5	24~400	6-20	352~1761
20	1~8	23~382	8-40	254~1273
25	1.5-12	21~320	10-70	161~1112
32	2-20	18~200	14-140	97~1172
40	2.5-25	10~190	25-200	134~1018
50	3-30	8~150	30-300	87~952
65	6-60	6~120	50-500	71~764
80	10-100	4.1~82	80-800	54~696
100	15-150	4.7~69	120-1200	42~548
125	25-250	3.2~57	1160-1600	26~346
150	30~300	2.8~43	250-2500	34~392
200	50-500	2~31	400-4000	23~326
250	80-800	1.5~25	600-6000	18.5~229

300	130-1300	1.2~24	1000-10000	16~216
-----	----------	--------	------------	--------

Vortex flow meter working condition flow range table

The working condition flow refers to the meter measuring the volume of the current medium passing through the pipeline. The medium is in the working state. For example, the gas can be compressed. When there is pressure in the pipeline, the volume after the gas is compressed is the working condition flow. The operating flow will change as the working environment changes.

Standard flow refers to the volume of the medium at standard atmospheric pressure and 0° (or 20°), when the compressed gas is released into the volume of the standard environment. The standard traffic does not change in any environment.

The measurement of the vortex flowmeter is the working volume. Only the temperature and pressure compensation can be used to obtain the standard volume. Generally, when used for trade measurement, the gas is mainly used as the standard condition, and the steam is usually measured by mass.

3. Instrument installation

- ◆ ☐ If the instrument is installed outdoors, add a sunshade to avoid sun and rain.
- ◆ ☐ Do not install in places subject to strong vibration.
- ◆ ☐ Do not expose to an environment that contains a lot of corrosive gases.
- ◆ Do not share power with equipment that pollutes power supplies such as inverters and welders, and install clean power if necessary.

A. Installation requirements for the environment:







1. Avoid strong electrical equipment and high-frequency equipment as much as possible, and avoid sharing power with these equipment.
2. Avoid high temperature, cold, corrosive or extremely humid environment. If it must be installed, instrument protection must be done.
3. When installing outdoors, it should be equipped with protective cover to avoid sun and rain. When the wiring is made, the instrument line is made U-shaped. When entering the case, the line is from bottom to top to avoid the rain entering the table along the line when it rains. Inside the shell.
4. The installation position should be fully considered when installing the instrument, and leave appropriate space for repairment and maintenance.

B. Installation requirements for the pipeline:

1. The pipe structure should be fully considered when installing the instrument. Pipe elbows or

valves should be avoided.

2. When installing the vortex street, the front and rear straight pipe sections should be fully reserved to avoid the error caused by the improper installation position of the instrument. (The figure below shows the pipe length requirements when the instrument is installed)

Sensor upstream	Front and rear straight pipe length	Sensor upstream	Front and rear straight pipe length
Concentric contraction fully open valve		a 90 degree elbow	
Two 90 degree elbows in the same plane		Two 90 degree elbows in different planes	
Concentric expansion		Regulating valve half open valve	


1、1. If it is necessary to install the regulating valve, the regulating valve should not be installed upstream of the meter, but should be installed at a distance other than 10D downstream of the meter. (D is the inner diameter of the meter, the same below)

2、2. When the instrument is installed, the upstream and downstream pipelines should be consistent with the inner diameter of the instrument. The error should not exceed 0.05D, and coaxial installation should be guaranteed.

3、3. If a gasket is installed between the instrument and the flange, the gasket should not be installed with eccentricity or too small to affect the flow condition.

4、4. When the split type is installed, the pressure measuring hole is installed in the range of 3~5D behind the meter, and the temperature measuring hole is reserved to be installed in the range of 6~8D at the back end of the meter. If it is not necessary, try to avoid installing it in front of the meter.




5、5. The instrument can be installed horizontally, vertically or obliquely on the pipe during installation. However, when measuring gas, if the pipe contains a small amount of liquid, in order to prevent the liquid from affecting the flow rate, it is recommended that the air flow flow from bottom to top. When measuring liquid, in order to ensure full meter measurement, it is generally recommended to install the pipe properly or obliquely, and the medium flows from bottom to top; if the liquid medium contains air bubbles, the meter should be installed at the lower part of the pipeline. (a is when the gas contains a liquid, and b is when the liquid contains a bubble)



C, plug-in vortex installation:

1. Use a gas weld on the pipe to open a round hole slightly smaller than $\Phi 100\text{mm}$, and clean the burrs around the round hole to ensure the fluent flow of the probe.
2. Solder the flange provided by the manufacturer at the hole in the pipe, and the flange axis is required to be perpendicular to the pipe axis.
3. Install the ball valve and sensor on the welded flange.
4. Adjust the lead screw so that the insertion depth meets the requirements (to ensure that the center axis of the probe coincides with the center axis of the pipe), and the fluid flow direction must be consistent with the indicator arrow on the direction mark.
5. Evenly tighten the screws on the gland. (Note: The tightness of the gland determines the degree of sealing of the instrument and whether the screw can be rotated)
6. Check that all the links are completed. Slowly open the valve to see if there is any leakage (special attention should be paid to personal safety). Repeat steps 5 and 6 if there is any leak.

D, installation taboo

			
Do not hold the meter when welding	Prohibit instrument reverse installation	Do not route with strong wires	Do not disassemble the internal components of the instrument without

			guidance
--	--	--	----------

4.Cable wiring

wiring:







- ◆ Do not operate with electricity
- ◆ Confirm the type and method of power supply

A	B	PIH	PVH	PVL	PIL	I-	I+	24+	Fout	24-
RS485		pressure transducer				4-20Ma		Power supply+	Frequency output	Power supply-

3.6+ 3.6- is the battery interface.


Users choose the appropriate wiring method based on different functional requirements.

Wiring diagram:



5. Debugging and running

First, the appearance of the introduction



B1 is the SHIFT button, B2 is the Δ button, and B3 is the SET button.

A:Buttons The board can be found through the appearance of three buttons. Their functions are:

SHIFT: a, switch screen. You can switch to the menu screen by pressing this on the main interface.

b. Switch the menu item and press this button on the menu screen to switch between different menus.

c. Shift key, in the parameter setting, you can use this button to shift.

d. Exit, in the parameter setting, press this button to exit the menu item without the displacement item.

Δ : The digital item plus function can adjust the number of the number according to the item that can input the number. The number size can be displayed cyclically. For example, if the current display is 6, it can be displayed as 8 for 2 times, or 1 for 3 more times.

SET: a, confirm the function, mainly after modifying the parameters, press this button to confirm the parameters.

b. Switch the menu. In the parameter setting, press this key directly to switch to other parameters, and the parameter list is displayed cyclically.

B, display

1. Display prompt line in the upper left corner: Under normal circumstances, Hz, PT, and OK are displayed. If there are obvious errors in the parameters, ERR will be displayed. PT represents the circuit board temperature and voltage compensation function, OK represents the circuit board self-test is normal, and Hz represents the sensor frequency.
2. The second row shows the instantaneous value: it consists of the instantaneous prompt word, the instantaneous value and the current unit.
3. The third row shows the accumulated value: it consists of the integral part of the accumulated value, the accumulated fractional part of the four digits and the unit.
4. The fourth row is the temperature and pressure state: the left side is the temperature mark, the temperature value and the temperature unit composition, and the right side is the pressure mark, the pressure value and the pressure unit.

Second、parameter settings

A、Main page display

F: 0.00HZ

PT OK

Instant0.00Nm3/h

00000000.0001

00000000.00Nm3

0.0℃0.0Kpa

In this interface, press the SHIFT key to enter the setup menu. ;

B、Parameter setting main interface

Press the SHIFT (Shift Select Menu) button

Common function

Common parameters

Calibration parameter


0000


In the main interface, press the SHIFT key to enter the main menu interface. You can use the SHIFT button to select the corresponding menu item and press the SET button to enter.

Language

English

In the main menu of the main interface, press the SET button to enter the common menu interface. Press the SET button to save and go to the next menu, and the arrow keys to modify the parameters.





↓

Gain:0

Under the rate menu, press the SET button to save and enter the rare menu. Press the SET button to save and go to the next menu, and the arrow keys to modify the parameters.

↓

conversion coefficient
10.000

Under the gain menu, press the SET button to save and enter the conversion coefficient menu. Press the SET button to save and go to the next menu, press the SHIFT button to move the cursor position, and the arrow keys to modify the parameters.

↓

Fmax:0
HZ
00000

Under the conversion coefficient menu, press the SET button to save and enter the Fmax menu. Press the SET button to save and go to the next menu, press the SHIFT button to move the cursor position, and the arrow keys to modify the parameters.

Flow Coefficient: 0
000000000.000

Under the Fmax menu, press the SET button to save and enter the Flow Coefficient:0 menu. Press the SET button to save and go to the next menu, press the SHIFT button to move the cursor position, and the arrow keys to modify the parameters.

Flow Coefficient
000003600.000

Under the Flow Coefficient:0 menu, press the SET button to save and enter the Flow Coefficient menu. Press the SET button to save and go to the next menu, press the SHIFT button to move the cursor position, and the arrow keys to modify the parameters.

Under the conversion coefficient menu, press the SET button to save and enter the equ menu. Press the SET button to save and go to the next menu, press the SHIFT button to move the cursor position, and the arrow keys to modify the

Equ
0000000000.000



alarm
0000000000.000



F: 0.00HZ PT OK
Instant 0.00 Nm3/h
0001
0 0 0 0 0 0 0 0. Nm3
0.0℃ 0.0Kpa



Common function
Common parameters
Calibration parameter
0000



F: 0.000HZ
Overflow: 0



F: 0.00HZ PT OK
Instant 0.00 Nm3/h
0001
0 0 0 0 0 0 0 0. Nm3
0.0℃ 0.0Kpa




Under the equ menu, press the SET button to save and enter the alarm menu. Press the SET button to save and go to the next menu, press the SHIFT button to move the cursor position, and the arrow keys to modify the parameters.


In the main interface, double-click to select the common parameter query.


In this interface, press the SET button to enter the common parameter query menu.

Under the Query menu, press the SET button to save and re-enter the main page display. The overflow flag is 1 when the flow rate exceeds 100000000. When this bit is greater than 10, it is automatically cleared. When the accumulated flow is cleared, this bit is also cleared. Press the SET button under this menu to return to the main page.

In the main interface, press three times to select the calibration parameter settings.







1、Common function settings:

Menu name	Parameter value	meaning
Language	0: Chinese, 1: English	Set the instrument language
alg	Volume (working conditions for volume) STPV (quality of work conditions) MASS(standard volume) STPm (standard quality) T comp (saturated steam) P comp(saturated steam) PT comp(superheated steam)	Different algorithms are used depending on the medium and the unit selected.
unit	m ³ /h; L/m; Nm ³ /h NL/m t/h kg/m m ³ /m; CFM Nm ³ /m kg/h	The unit of the fluid to be displayed, the unit must match the algorithm.
Fout	0	Frequency output options 0, original pulse 1. Correct pulse 2. Equivalent output (high level=24V, low level=0)
Full flow	1000	Set the instantaneous flow rate corresponding to the full scale at 20mA current output (not allowed to be set to 0). The unit is the same as the unit selected in Unit Selection.
Density	1000	Set the density value of the fluid in units of kg/m ³ (not allowed to be set to 0) (quality algorithm needs to calculate the density value of this setting, it does not work for volume class algorithm and steam algorithm)
Lower cut	0000	The setting is lower than the set frequency and the flow is not displayed (used to eliminate interference caused by environmental conditions when static).
password	0000	Used to set the password to enter the parameter menu, the site administrator can modify the password to prevent malicious tampering with parameters.
mail address	01	Set the 485 communication address of the slave
P	00.00	It is used to set the pressure when setting. If the sensor is automatically collected, this menu and temperature setting menu must be 0 at the same time. If one item is not 0, it will become the fixed value calculation. (Note here is the gauge pressure).

T	00.00	It is used to set the temperature when setting. If the connected sensor automatically collects this menu and the pressure setting menu must be 0 at the same time, if one item is not 0, it will become the fixed value calculation.
Flow clear	clear	Clear accumulated traffic.
Rate	0	Set to 1-bit filtering algorithm for field flow instability
gain	0	Probe signal gain setting, 0 is low and 1 is high.
conversion coefficient	10.00	Seismic setting, set to 00.003 if necessary
Fmax	0	upper limit values, calibration upper limit 0 and 1 setting 2 and 3 are 0, then 3 points are calibrated, and the upper limit of calibration 0, 1, 2, 3 is set to 5 points.
Flow Coefficient	0000	The flow meter factor required to calculate the flow rate, where the four coefficients correspond to the four-stage calibration of the upper and lower calibration limits.
Flow Coefficient	3600	The flow meter factor required to calculate the flow rate, where the four coefficients correspond to the four-stage calibration of the upper and lower calibration limits.
Equ	0	Output the number of pulses corresponding to the accumulated traffic, used for IC card control, with a minimum equivalent of 0.0001
alarm	00	Set the alarm value. Selecting 1 as the lower limit alarm and 0 as the upper limit alarm.

2, calibration parameter settings:

Note: The following menus are not allowed for private transfer by non-professionals.

Private transfer may result in inaccurate temperature.

Menu name	Parameter meaning
4mA: 4.0000	Calibrate 4 mA. This menu must be re-set to 4 for calibration. The high-precision 16-bit DA conversion chip AD421 is used, which is
20mA: 20.000	Calibrate 20 mA. This menu must be reset to a parameter of 20 for calibration. Ibid.
P min	Pressure zero check value.
P max	Pressure full scale check value.
P ran	Pressure range.
P+: 0, p-:1	Pressure mode, positive or negative pressure, used for negative pressure setting at constant pressure.
PB/PJ	PB is a gauge pressure sensor, PJ is an absolute pressure sensor
LocalP:101.3	Local atmospheric pressure setting.
Tco:50	Temperature linear correction, the default is 50. For example, if the main interface is 100 ° C, the standard is 101 ° C, here is set to 51, if the standard is 99 ° C, set here to 49.
PT100/PT1000	Temperature sensor selection
T0/T20	T0 is the standard gas volume of 0 ° C an atmospheric pressure, T20 is 20 ° C, used for the calculation of the standard gas volume flow. Generally, natural gas is 20 ° C standard, others are 0 ° C.
T:0/T:1	The temperature sensor compensates for the temperature inside and outside the medium, with T: 0 inside and T: 1 outside.
BRT: 1	485 baud rate setting. 0 corresponds to 4800, 1 corresponds to 9600, 2 corresponds to 19200, and 3 corresponds to 38400.
None/Odd/Even	485 verification settings. None corresponds to no parity, Odd corresponds to odd parity, and Even corresponds to even parity.

Third, the dial switch settings

The vortex flowmeter adjusts the performance of the instrument with different calibers by adjusting the dial switch. In the vortex flowmeter, there are 5 sets of dial switches, which are located on the main board below the display screen, and are marked with GB (4 groups) and SB (4 groups), K1, K2, K3 printed lettering

GB and SB are four groups of dialing codes, the function of which is signal gain, which can be simply understood as sensitivity. The normal factory GB is 1, 2 is on, SB is 3 is on, the meaning is

Dial code	1	2	3	4
value	1	2	4	8

In normal use, the sum of the values corresponding to the dialing bits is used, and the larger the value, the higher the sensitivity. The functions of .K1, K2 and K3 are signal filtering, and each of their meanings is different. Here, the common caliber and medium corresponding setting values are provided. Of course, due to the difference in the meter itself, it may be slightly different from the table below.

liquid			
caliber	K1	K2	K3
15	1357	5	123
20	1357	5	123
25	1357	5	4
32	1357	5	4
40	1458	7	1234
50	1458	7	5
80	1458	67	45
100	1458	67	6
125	1458	8	7
150	1458	8	7
200	48	8	8
250	3478	78	78
300	3478	78	78

gas			
caliber	K1	K2	K3
15	1256	1	1
20	1256	1	1
25	1256	2	2
32	1256	2	2
40	1357	2	2
50	1357	2	3
80	1357	3	13
100	1357	3	123
125	1357	4	123
150	1357	4	4
200	1458	5	4
250	1458	6	1234
300	1458	7	5

Fourth, common problems

1. The amount of field instrument frequency change is large, and the elimination method is as follows:

A. First check whether the straight pipe section meets the requirements. The gas can be relaxed to ensure the straight pipe section of the 5D after the first 10D. The liquid straight pipe section does not meet the requirements, and the straight pipe section is not long enough. It is recommended to change the installation position. B. There may be electromagnetic interference at the scene. Method: Enhance the filtering function, reduce the sensitivity, and realize by dialing the code switch. C. The on-site flow is too small, lower than the lower limit of the instrument. For example, the plug-in gas of 300 caliber has a lower limit of 1500m³/h, but the field indicates an instantaneous flow of about 500 m³. Because the flow rate is at the lower limit, the value does not change linearly. Change the meter factor to increase traffic (not recommended). D. A similar situation can occur when measuring the pulsating flow of a liquid.

2. There is 50HZ interference on site, generally the shielded wire is not grounded.

3. No flow signal at the scene. A. The instrument small signal cut is too large, can be modified in the parameter setting; B. The power supply is not connected, no power; C. The flow rate is very low and the signal trigger point is not reached; the D.4-20mA output table is not set before leaving the factory. Range.

4. The actual flow rate increases, the instrument display can be reduced, and the reasons for the on-site working conditions (such as pipeline technology) can be checked.

5. The actual flow rate is reduced, and the meter display is increased. Most of the pipes are vibrating or the gasket is not at the center of the pipe during installation. The instrument should be reinstalled.

6. The instrument display of the same working condition is inconsistent, and the difference is large. A. The customer's experience value is wrong, or the working condition is different, such as the problem of pipeline orientation, the problem of straight pipe section, the problem of vibration, etc.; B. The customer has modified; C. The working condition flow is too low, the lower limit is not linear; D. The temperature and pressure compensation table, the temperature pressure is faulty.

7, 4-20mA output meter, display and system display are inconsistent. A. The unit of parameter setting is inconsistent, or the range is not consistent; B.4-20mA output cable is too long (more than 1000 meters), and the loss is large.

8. The flow rate displayed by the meter differs greatly from the actual one. Most of the reason is the problem of the parameter setting unit.

9. The static flow of the instrument is mostly caused by vibration of the pipeline on the site. Damping measures or reducing the sensitivity of the instrument can be alleviated or eliminated.